

<b>SeedCommand™ AutoSwath Function</b>	<b>Problem</b>	<b>Recommended Action</b>	<b>Result</b>
Turn On Look-Ahead (leaving headlands)	Overlaps	Decrease look-ahead number.	The <b>AutoSwath</b> anticipates headlands later and turns the planter on later.
	Skips	Increase look-ahead number.	The <b>AutoSwath</b> anticipates headlands sooner and turns the planter on sooner.
Turn Off Look-Ahead (driving into headlands)	Overlaps	Increase look-ahead number.	The <b>AutoSwath</b> anticipates headlands sooner and turns the planter off sooner.
	Skips	Decrease look-ahead number.	The <b>AutoSwath</b> anticipates headlands later and turns the planter off later.



Chris: 641-751-3936  
Alec: 641-257-7989

[www.ptprecisionag.com](http://www.ptprecisionag.com)

Check us out! 

@PTprecisionag

### INTEGRA/VERSA INSTRUCTIONS

1. From the home screen press the **WRENCH**.
2. Highlight current configuration by pressing on it.
3. Press the **WRENCH** in the middle of the screen.
4. Press the **Automatic Swath Control** button.
5. Change Look-Ahead by pressing on the buttons on the right side of the screen. See front of sheet for instructions.
6. Click the **Green Check Mark** to save.

### INSIGHT INSTRUCTIONS

1. Press the **WRENCH** on the right of the screen.
2. Press your operation type (i.e. planting for planter)
3. Highlight current configuration by pressing on it.
4. Press the **Automatic Swath Control** Button.
5. Change Look-Ahead by pressing on the buttons on the left side of the screen. See front of sheet for instructions.
6. Click **Accept** button to save.