



PN 2002831-49 Rev A



### Row Performance screen

The Row Performance screen displays information on specific rows.

Press Advanced Seed Monitoring button to view Advance Seed Monitoring screen with seed trench.



PN 2002831-49 Rev A



#### Seed Monitor Options screen

The Seed Monitor Options screen adjust Seed Tube Monitor Module alarm thresholds.





### ASM Recommended Thresholds

Row Spacing									Dbls	Spacing
15	18	20	22	28	30	36	38	40	Threshold	Threshold
139,392	116,160	104,544	95,040	74,674	69,696	58,080	55,023	52,272	1.5	2.5
119,479	99,566	89,609	81,463	64,007	59,739	49,783	47,163	44,805	1.5	2.5
104,544	87,120	78,408	71,280	56,006	52,272	43,560	41,267	39,204	1.7	2.5
92,928	77,440	69,696	63,360	49,783	46,464	38,720	36,682	34,848	2.0	3
83,635	69,696	62,726	57,024	44,805	41,818	34,848	33,014	31,363	2.3	3.5
76,032	63,360	57,024	51,840	40,731	38,016	31,680	30,013	28,512	2.6	4
69,696	58,080	52,272	47,520	37,337	34,848	29,040	27,512	26,136	2.9	4.5
64,335	53,612	48,251	43,865	34,465	32,167	26,806	25,395	24,126	3.2	5
59,739	49,783	44,805	40,731	32,003	29,870	24,891	23,581	22,402	3.5	5.5
55,757	46,464	41,818	38,016	29,870	27,878	23,232	22,009	20,909	3.8	6
52,272	43,560	39,204	35,640	28,003	26,136	21,780	20,634	19,602	4.1	6.5
49,197	40,998	36,898	33,544	26,356	24,599	20,499	19,420	18,449	4.5	7
46,464	38,720	34,848	31,680	24,891	23,232	19,360	18,341	17,424	4.5	7
44,019	36,682	33,014	30,013	23,581	22,009	18,341	17,376	16,507	4.5	7
41,818	34,848	31,363	28,512	22,402	20,909	17,424	16,507	15,682	4.5	7
Population										

- Singulation Alarm Threshold: 98%

- Spacing Alarm Threshold: 98%

\* The system will alert the operator with a yellow flashing box on the Planter Performance screen identifying the mis-performing function.







